


## User Guide for Smart Control Panel that will install on 1500 It Pumps.



**1)Manometers:** In this section, there are 2 manometers to show the Pressure of the pump in 2 stages. The first one shows low pressure, the second shows vacuum pressure.

The range of this manometers are as follow:

- Low pressure: 0~25 Bar
- Vacuum pressure: -1~15 Bar

2) *Electric switches*: In this section, there are 3 switches, and a light.

All components are describing at below:

- **Emergency Stop**: It will use to turn on the LCD and whole switches and use to turn them off.



- **Alarm**: This **Red** light in Emergency Stop switch will be lit up at start and will lit up and off to show the warnings in system in 2 conditions that are describing at below:
  - When water tank level is less than 20%
  - When the rotational speed is more than 4000 rpm.
- **Vacuum**: By pushing this key, the vacuum mode of the pump will start and you can use it to vacuum water. If the pressure reaches 1 bar, it will automatically cut off the Prime.



- **Start/Stop**: It will use to turn on the LCD and whole switches and use to turn them off.



- ❖ **Electric connector**: Whole wires to connect the panel with sensors and battery are here to use.

Note: For more details of wiring please check the wiring file for each panel(1500,2000 or 3000 lit/min panels.)



- ❖ **Memory Card:** It is used to save all parameters in it for doing better aftersales services. It is located backside of LCD shown as bellow.




**3) LCD:** In this section, you can monitor parameters as below:

1. The time that panel already has been turned on.
2. Number of pages that data are saving in memory.
3. Water tank level
4. Warnings

<b>WARNING</b>	Check W.T.L Sensor/Wire
<b>WARNING</b>	Water Tank Near to Empty
<b>WARNING</b>	R.P.M out of SAFE RANGE

5. Rotational speed of pump in R.P.M.



**Note: Whole switches, manometers and LCD has Label to help user to find his way on panel.**